Recharge Components

Recharge and rebuild tools and kits are available for disassembling the valves after a discharge. O-ring kits are available to replace internal valve o-rings after a discharge.

Spanner Wrench – Part No. 570574

This tool is required to remove the valve bonnet assembly for access to the valve piston and o-ring replacement on 1 and 2 in. valves.

Recharge Adaptors

Top Adaptor Assembly for 1 and 2 in. Valves – Part No. 570579

Fill Adaptor Assembly for 1 in. Valve – Part No. 570576

Fill Adaptor Assembly for 2 in. Valve – Part No. 570592

Fill Adaptor Assembly for 3 in. Valve – Part No. 69891

Rebuild Kits

Rebuild Kit for 1 in. Valve – Part No. 570559 (contains bonnet o-ring, collar o-ring, siphon tube o-ring)

Rebuild Kit for 2 in. Valve – Part No. 570584 (contains bonnet o-ring, collar o-ring, siphon tube o-ring)

Rebuild Kit for 3 in. Valve – Part No. 570373 (contains top cap o-ring, complete piston assembly, collar o-ring)

ANSUL and SAPPHIRE are trademarks of Ansul Incorporated or its affiliates.

INDOREED THE LEADING OF FIRE COMPANY PROVIDERS