

Control Heads

LOCAL MANUAL CONTROL HEAD

- Used for manual actuation of cylinder
- Equipped with safety pull-pin to prevent accidental manual discharge of Clean Agent
- · Self-venting
- · Solid brass construction
- · Stainless steel operation lock-pin

The Local Manual Control Head features a local lever driven push rod that depresses a Schrader check valve, thereby venting the pressure from the top of the piston in the cylinder valve, allowing the piston to slide upward and commence cylinder discharge. The Local Manual Control Head mounts directly to a top plug adapter, which is located on top of the cylinder valve.



P/N: CP 61033

PISTON ACTUATOR

- · High quality brass construction
- Mounts directly on top of cylinder valves
- · Self-venting

The Piston Actuator features a pneumatically driven piston that depresses a Schrader check valve, thereby venting the pressure from the top of the piston in the cylinder valve, allowing the piston to slide upward and commence cylinder discharge. The pneumatic pressure required to operate the Piston Actuator is obtained from the "M" port of a cylinder that is designated as "Master" cylinder and is either mechanically and/or electrically actuated. Multiple cylinders equipped with Piston Actuators can be activated from one master cylinder using 1/4" copper tubing or 1/4" metal flex hose. The Piston Actuator mounts directly to a top plug adapter, which is located on top of the cylinder valve.



P/N: CP 61041